D212-838-011 POD MODIFICATION KIT (COMPATIBLE WITH D212-601-041/-042 HELI-UTILITY-POD) (RH INSTALLATION SHOWN, LH INSTALLATION OPPOSITE) (INSTRUMENTS NOT SHOWN FOR CLARITY) 1) MATERIAL: NONE 2) FINISH: NONE 3) TOLERANCES: PER DART QSI 018 UNLESS OTHERWISE NOTED 4) UNITS: INCHES UNLESS OTHERWISE NOTED 5) BREAK SHARP EDGES: N/A 6) IDENTIFICATION: NONE 7) WEIGHT: 20 lbs APPROX 8) FOR INSTALLATION OF D4172-041 FRAME AND 80-005-3-8 INSERTS:
8.1) LOCATE D4172-041 FRAME INSIDE POD SO THE FASTENER HOLES ARE MORE OR LESS ON THE CENTERLINE OF EACH D2200-3 POD RIBS; 8.2) TRANSFER MARK AND DRILL SAME SIZE DIAMETER AS THE INSERT SHAFT DIAMETER TO A MAXIMUM OF 1.250" DEEP; 8.3) CLEAN OUT FOAM CORE \emptyset 0.125" TO 0.250" AROUND HOLE BETWEEN OUTER AND INNER SKINS; 8.4) FOR EACH CAVITY, FILL ONE THIRD WITH "HYSOL EA394" OR EQUIVALENT EPOXY COMPOUND; 8.5) INSTALL 80-005-3-8 INSERTS BY FILLING THE CAVITY WITH "HYSOL EA394" PER QSI 006 14.6 ENSURING INSIDE OF INSERTS ARE FREE OF

	ITEM	QTY -011	P/N	DESCRIPTION	
		Х	D212-838-011	POD MODIFICATION KIT	
8	1	1	D4172-041	POD MOUNTING FRAME ASSY	
	2	1	D4181-3	POD FRAME PLATFORM	
	3	1	D4319-3	SPACER	
	4	2	D4319-5	GPS BRACKET	
	5	11	D4319-7	ALTIMETER BRACKET	
	6	1	D4319-9	ALTIMETER BRACKET	
	7	4	D4320-1	ANGLE BRACKET	
11>	8	2	D4781-041	DOUBLER ASSY	
[11>	9	1	D4781-1	DOUBLER	
11>	10	1	D4781-3	DOUBLER	
	11	1	D4781-5	DOUBLER	
	12	1	D4782-041	PLATE ASSY	
13	13	1	D4813-1	DOUBLER	
[13]	14	1	D4813-3	DOUBLER	
	45		00.005.0.0	DOTTED INCEPT	
8	15	8	80-005-3-8	POTTED INSERT	
	16	10	AN3-5A	BOLT	
	17	6	AN3-10A	BOLT	
12	18	8	AN4-4A	BOLT	
	19	5	AN4-7A	BOLT	
	20	4	AN4-12A	BOLT	
	21	16	MS21042L3	NUT	
	22	4	MS21042L4	NUT	
	23	12	MS24694-S100	SCREW	
	24	32	NAS1149D0363J	WASHER	
[25	8	NAS1149F0432P	WASHER	
	26	13	NAS1149D0463J	WASHER	
12>[27	A/R	N/A	SHIM	

Α	NEW ISSUE ME			MB	13.03.15	
REV.			DESCRIPTION BY			
DESIGN		B	DART AEROSPACE LTD			
DRAWN		B	HAWKESBURY, ONTARIO, CANADA			
CHECKED		ASS	DRAWING NO. D212-838		REV. A	
MFG. APPR.		\overline{N}			SHEET 1 OF 4	
APPROVED -			TITLE		SCALE	
DE APF	PR.	-#	POD MODIFICATION KIT		NTS	
DATE 13.03.15			COPYRIGHT © 2013 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OF COMEIN OF CAMBUNICATED TO ANY OTHER PERSON WITHOUT			

13.1) LOCATE D4813-1 DOUBLER INSIDE POD LID.
13.1) LOCATE D4813-1 DOUBLER INSIDE POD LID.
13.2) TRANSFER MARK AND DRILL ALL HOLES THRU AS INDICATED IN VIEW K (ZN D6-4) EXCEPT QTY(6) \$\omegain 0.201 SHOULD BE DRILLED TO \$\omegain 0.313.
13.3) CLEAN OUT FOAM CORE \$\omegain 0.125" TO 0.250" AROUND QTY(6) \$\omegain 0.313 HOLE BETWEEN OUTER AND INNER SKINS;
13.4) FILL EACH HOLE/CAVITY WITH "HYSOL EA394" OR EQUIVALENT EPOXY COMPOUND AND LET CURE;
13.5) GRIND TO A SMOOTH SURFACE AS REQUIRED AFTER EPOXY HAS COMPLETELY CURED;
13.6) DRILL QTY(6) \$\omegain 0.201 HOLE THRU HARDENED "HYSOL EA394" OR EQUIVALENT EPOXY COMPOUND. DEBURR;
13.7) TOUCH UP FINISH USING DUPONT HIGHBUILD PRIMER GREY #1104S.OR #1144S.
13.8) WET INSTALL D4813-1/-3 USING SIKAFLEX -241/-291 ADHESIVE

8.6) GRIND TO A SMOOTH SURFACE AS REQUIRED AFTER EPOXY HAS COMPLETELY CURED; 8.7) TOUCH UP FINISH USING DUPONT HIGHBUILD PRIMER GREY #1104S OR #1144S.

9) MOUNTING HOLE LOCATIONS FOR D4781-041 SHOULD BE CENTERED BETWEEN RIBS AT BOTTOM OF D2200-3 POD BASE.
10) SEAL EDGES OF ALL DRILLED HOLES AND CUTOUTS WITH CYANOACRYLATE GLUE (CRAZY GLUE)
11) WET INSTALL D4781-041/-1/-3 USING SIKAFLEX -241/-291 ADHESIVE

12) IT IS ACCEPTABLE TO USE LONGER AN4 BOLTS AND INSERT SHIMS AS REQUIRED BETWEEN THE POD RIBS AND D4172-041 FRAME.

MANUFACTURE 1.00" X 1.00" SHIMS TO REQUIRED THICKNESS FROM M6061T6S OR M6061T6B ALUMINUM

13) FOR INSTALLATION OF D4813-1/-3 DOUBLERS ONTO POD LID:

8

POTTING COMPOUND;

5





